


ACOUSTIC SLAT (CURVED) INSTALLATION GUIDE



Installation Guide – Suspended Acoustic (Curved) Slats

1. Material Preparation

- Curved slats (quantity required depending on the surface area).
 - Suspension cables or rods with ceiling-compatible hooks.
 - Dowels and screws suitable for the ceiling type (concrete, suspended, etc.).
 - Spirit level or laser level.
 - Measuring tape.
 - Drill-driver.
 - Secure step ladder.
-

2. Installation Steps

Step 1: Marking the Fixing Points

1. Measure the installation area and determine the spacing between the curved slats (example: 30 cm between each slat).
 2. Mark the suspension points on the ceiling for each cable (generally 2 cables per slat).
 3. Check alignment with a laser level to ensure regularity.
-

Step 2: Installing the Ceiling Fixings

1. Drill at the marked locations.
 2. Insert the appropriate dowels.
 3. Screw in the suspension hooks or anchors.
-

Step 3: Attaching the Cables or Rods

1. Screw or hook the cables/rods to the ceiling fixings.
 2. Adjust the length to maintain a minimum distance of 25 cm between the ceiling and the top of the slats.
 3. Ensure all cables are at the same height.
-

Step 4: Mounting the Slats

1. Hook the first slat to its two cables.
 2. Check horizontality with a level.
 3. Repeat for the other slats, keeping the planned spacing (example: 30 cm between each slat).
-

Step 5: Adjustments and Finishing

1. Check the alignment of the entire installation.
 2. Adjust cable height if necessary.
 3. Tighten all fixings.
 4. Clean the slat surfaces if needed.
-

3. Safety Tips

- Always work in pairs (one person holds, the other fixes).
- Use a stable and suitable step ladder.
- Wear safety glasses and gloves when drilling.

